


Maintenance Free Dust Filters for Underground Mines



Steven Schafrik
Associate Professor
Department of Mining Engineering
University of Kentucky



Sept 6th, 2019



Acknowledgements

A majority of this work was made possible by the National Institute for Occupational Safety and Health (NIOSH) for funding this research via the contract 200-2014-59922, "Coal Mine Dust Mitigation Through Novel Scrubber Development and Numerical Modeling". The views, opinions, and recommendations expressed herein are solely those of the presenter and do not imply any endorsement by the CDC/NIOSH

Outline

- Mining scrubber systems
- Computer (CFD) modeling of Vortecone
- Lab testing for cleaning efficiency on a reduced scale prototype
- Self-cleaning impingement filter – Modeling and experiments
- Analysis of the conventional fibrous type screen filter
- Vortecone, impingement, and conventional filters compared


Target: Flooded Bed Scrubbers



- Inlet, duct work : Captures and directs air
- Fibrous screen : Captures particles from the airstream
- Water spray : Assists capture, prevents dust accumulation
- Demister : Removes excess moisture
- 60-90 % dust reduction [outdated numbers, update coming]
 - Maintenance intensive, screen clogging


The Vortecone Filter

- Automobile painting generates over-sprays [1-300 μm]
- Very High Cleaning efficiency, no maintenance




The Vortecone Mechanism

- Fluids accelerated into the vortex chamber
- Particles cast out of swirling airstream differentially based on mass
- Dirty air and water enter air and dirty water leave




Rapidly Swirling Water Film




- Flow sensitive to geometry
- No internal data acquisition system

CFD Modeling

- Steady State Models:
 - Shows flow parameters when averaged over a long duration
- Transient State Models and the VOF
 - Volume of fraction (VOF) approach to mimic the air-water interface
- Dust Particle Transportation and Tracking
 - Cleaning efficiency with particle size
 - User defined functions to model particle trapped by water film and not on impermeable Vortecone surface; good agreement with experiments





Laboratory Testing



- VFD, Centrifugal fan, Vane and rail equipped duct [12" X 18"]
- Pressure [P_T and P_S] measurement
- Full-cone water spray with controller
- 3D printed Arduino controlled dust feeder
- TSI OPS 3330 – Used 9 particle size channels





Iso-kinetic Sampling of Airflow [Fixed OPS Flow= 1.0 l/min]



- Optical properties - Complex refractive index
- Experimental errors are eliminated by randomly running tests

Cleaning Efficiency




- Cleaning efficiency, $\eta = a(1 - e^{-bd})$ [Used for all filters]
 - [a and b : Constants for a known set of flows, d : particle diameter]
 - Area under curve indicates particle capture

Initial Hypothesis


- Vortecone cleaning and maintenance free operation make it an attractive alternative to conventional screens

Lab Testing: Vertically Upright Orientation

- Efficiency improves with an increase in flow and particle size
- Higher efficiency in the vertically upright orientation




The Problem: High Capture at a Price



- Native Vortecone in Horizontal Orientation
- Conventional Fibrous Screen


Parametric Studies of the Vortecone

- Rapid acceleration requires power
- Investigation of a few parameters
 - Guide flaps [23_a]
 - Radius of the vortex chamber [32]
 - Sharp curve at the bottom [30_a]
- Vortecone redrawn
 - CFD models for system curve
 - 48 % less resistance (pressure drop and power needed)




The Redesign

- Parametric study to determine the features that dictate flow and pressure drop
 - Length and width of guide flaps
 - Radii of lobes
 - The sharp curve at the lower end of the Vortecone



Horticone

- Design for horizontal implementation, Vortecone with one outlet
- Wider inlet guide to slow down airflow to just the minimum speed, lowers the power requirements significantly



Works Better

- Vortecone provides a very high capture rate, leading to great efficiency
- Hortecone is a step change improvement, especially for working in underground environments
- Both require a redesign of the flooded bed scrubber



The Conventional Fibrous Screen: Lab Set-up

- Water flooded screen recommended by the USBM
 - Usually 10-30 layered screen used in the industry
 - Used a 20 layered screen for lab testing




Conventional Screen Laboratory Results

- Cleaning efficiency improved with increase in dust size and airflow
- Water flow affecting efficiency at the lower airflow



Designing the Impingement Type Filter*


- Three thin aluminum sheets with wide, long rectangular slits
- Designed screen separation to force acceleration



* US Patent and Trademark Office, Application # 62/74,6711



Particle Tracking for Impaction

- Released 'mass-particles' with a wide range of diameter at the inlet;
- Particles hitting the screen assumed to be trapped




Lab Testing of the Impingement Screen

- Modified the test set-up for impingement screen testing
 - Dust injected upstream of the screen, sampled iso-kinetically
- increase in airflow





Filters Performance Compared

- Used the same set-up for the PQ and cleaning efficiency curves
 - $P = RQ^2 \Rightarrow \log P = \log R + 2. \log Q$ [straight line]
 - Vortecone shows highest resistance (pressure-drop) to flow



Screen	Resistance (kN.s ² /m ⁸)	Compared to Vortecone
Vortecone	22.99	100.0
Impingement	3.43	14.9
Conventional	3.13	13.7
Horticone	1.73	7.52

Cleaning Efficiency Comparison [6.0 gpm]



- Consistent air and water flows

Filter Performance Factor [FPF]

- $$FPF = \frac{1}{P} \int_{dS}^{dL} a(1 - e^{-bd}) \cdot dd$$



Area under the cleaning efficiency curve (Integral)

Table. FPF calculations at 600 and 800 cfm

Cut-off sizes	Vortecon e	Impingement Screen	Conventional Screen	Cut-off sizes	Vortecon e	Impingement Screen	Conventional Screen
Integral	988	915	961	Integral	1,029	967	1,004
P (in.wg.)	7.99	1.24	1.02	P (in.wg.)	14.18	2.21	1.82
FPF	123	738	942	FPF	73	437	552

A filter with a high FPF is desirable.

Conclusions

- Combination of computer simulation and physical model in rapid prototyping results in filters with competitive performance
- Long term, Vortecones or the Horticone make great filters where water is present or can be recycled
- Short term, impingement screen replacements for conventional screens provide comparable cleaning results, at comparable pressure drops, and added benefit of maintenance free operation
- Follow on project just started taking the impingement screen technology, improving it and deploying it underground

